



Xotic Bass XB Series Control



1. Master Volume
(Push: Series & Pull: Parallel for Front Pickup)

2. Master Tone
(Push: Series & Pull: Parallel for Rear Pickup)

3. Balancer

4. Bass EQ

5. Mid EQ

6. Treble EQ

7. Passive /Active Switch



8. Mid EQ Frequency Selector

9. Active Output Gain Control

Xotic Bass Preamp

Three Band EQ (high, mid, low) boost & cut. Center position produces flat, unaltered sound, with no added tonal coloration.

*Mid selector switches for a choice of four different pre-set mid frequencies, from low-mid to high-mid (located in back panel for easy access).

*Pre-set gain control to boost gain by one to three times (located in back panel for easy access).

*18V drive is for more headroom, which allows incoming signals to pass through cleanly, without clipping the high-end or low-end frequencies. (Requires two 9V batteries)

[Xotic Bass Preamp Frequency Specification]

HIGH: @10kHz, +14dB, -12dB

MID1 (Mid select switches: sw1-off, sw2-off): @3kHz, +9dB, -9dB

MID2 (Mid select switches: sw1-on, sw2-off): @1kHz, +12dB, -10dB

MID3 (Mid select switches: sw1-off, sw2-on): @800Hz, +4dB, -4dB

MID4 (Mid select switches: sw1-on, sw2-on): @400Hz, +8dB, -10dB

LOW: @20Hz, +10dB, -10dB